
PL-D7620 Timing Diagram

Note: The PL-D7620 camera model can currently output half of its maximum frame rate when it is software of hardware triggered since only every second frame gets delivered to the host.



Picture 1. Timing diagram for trigger pulses.

Table 1.1 Signal Information

Signal	Description	Min	Тур	Max
3161101	Board Level		·γρ	IVIGX
	hardware			
t1	propagation delay		10 ns	
	(3.3V HCMOS to trigger)			
	Enclosed hardware		8 us ON	
	propagation delay (5V to		30 us OFF	
	trigger optocoupler)		(Note 1)	
	Enclosed hardware		2.5 us ON	
	propagation delay (12V to		40 us OFF	
	trigger optocoupler)		(Note 1)	
t2	Debounce time		1.0 us	
			varies between	
t3	1H period	0.0 us	Min and Max	See Table 1.2
t4	Programmable GPO delay	0.0 us	in 10 us steps	2.5 sec
-	Start of trigger to start of			
t5	GPO			
	(t1 + t2 + t3 + t4 + t18)			
t6	Programmable GPO time	10.0 us	in 10 us steps	2.5 sec
	Trigger mode 14		·	
t7	Programmable integration	0.0		2.5
	delay	0.0 us	in 10 us steps	2.5 sec
	(Note 2)			
t8	Communication		See Table 1.2	
t9	Integration shutdown period	11.0 us	1/(frame rate) - t10	
t10	Integration time		See <u>Integration Times</u>	
	Start of trigger to start of			
t11	second frame integration		t1 + t2 + t7 + t3 + 2·t8 + 2·t9	
	(Note 3, 4)			
t12	Read out time		See Readout Times	
	(Note 5)			
t13	Start of trigger to start of		+10 + +11	
(13	second frame read out		t10 + t11	
t14	End of read out to start of		t17 - t12 - t13	
(14	trigger		117 - 112 - 113	
t15	Start of trigger to start of		t1 + t2 + t3	
	busy		11 1 12 1 13	
t16	End of busy to start of trigger	30.0 ns	t17 - t12 - t13 - t3 _{Max}	
t17	Frame period		t12 + t13 + t14	
	Board Level			
t18	hardware			
&	propagation delay		20 ns	
t19	(3.3V HCMOS			
	From GPO)			
	Enclosed hardware		3 us ON	
	propagation delay		70 us OFF	
	(GPO optocoupler		(Note 1)	
	with 1K pullup to 5V)		(

Note:

- 1. "ON" refers to current flowing through the optocoupler and "OFF" refers to no current flowing through the optocoupler. Refer to <u>interface schematics</u>.
- 2. For minimum hardware trigger, the programmable integration delay (t7) should be set to 0 (minimum).
- 3. For a software trigger, $t11 = 1.7 \text{ ms} + (2 \cdot t8 + 2 \cdot t9) \text{ typical}$.
- 4. The second frame integration is provided since only every second frame gets delivered to the host (see Note 5 below).
- 5. Camera readout time indicates the start of the second frame readout since only every second frame gets delivered to the host after software or hardware trigger is detected.

Table 1.2 Maximum of 1H and Communication period for PL-D7620 camera

PL-D7620	For 8-bit output in (us)	For 12-bit output in (us)
1H Max	12.417	14.890
Communication	86.920	116.670