Signal	Description	Min	Тур	Max
	EMV hardware propagation delay (3.3V TTL to trigger)		10 ns	
	MV hardware propagation delay (5V to trigger optocoupler)		8 us ON	
	(ov to trigger optocoupler)		30 us OFF	
t1	MV hardware propagation delay		(Note 1) 2.5 us ON	
	(12V to trigger optocoupler)		40 us OFF (Note 1)	
t2	Debounce time	1.0 us	1 us (default for Rev 4)	50.0 us (default for Rev 3)
t3	Programmable GPO delay	0.0 us	in 10 us steps	2.5 sec
t4	Start of trigger to start of GPO (t1 + t2 + t3 + t15)		9.0 us	
t5	Programmable GPO time	10.0 us	in 10 us steps	2.5 sec
t6	Programmable integration delay	0.0 us	in 10 us steps	2.5 sec
t7	Start of trigger to start of		25.0 us	
	integration (t1 + t2 + t6 + t17)		(Note 2)	
t8	Integration time	10.0 us	in 10 us steps	1.0 sec
t9	End of integration to start of read out		1.0 us	
t10	Read out time		See Readout Times	
t11	End of read out to start of trigger	0.5 us (no updates)	depends on updates	7.0 us (with descriptors)
t12	Start of trigger to start of busy		t1 + t2	
t13	End of busy to start of trigger		25.0 ns	
t14	Frame period		t7 + t8 + t9 + t10 + t11	
	EMV hardware propagation delay		20 ns	
t15	(3.3V TTL from GPO)			
&	MV hardware propagation delay (GPO		3 us ON	
	optocoupler with 1K pullup to 5V)		43 us OFF	
t16			(Note 1)	
t17	Array fast reset time		6 us + 3.6 us per row	